

INSTALLATION INSTRUCTIONS

MONTAGEANLEITUNG

INSTRUCTION DE MONTAGE

MANUALE DI INSTALLAZIONE

INSTRUCCIONES DE INSTALACION

ΟΔΗΓΕΣ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ

GB	Description: SUNSHADES Application: JIMNY 3DR	Partnumber: 0078338BC Installation Time: 0.15h
D	Beschreibung: SONNENSCHUTZ Verwendung: JIMNY 3DR	Teile Nr: 0078338BC Montagezeit: 0.15h
F	Designation: PARE-SOLEIL Utilisation: JIMNY 3DR	n° de piece: 0078338BC Temps pose: 0.15h
I	Descrizione: SOLE OMBREGGIA Applicazioni: JIMNY 3DR	Numero di codice: 0078338BC Tempo di installazione: 0.15h
E	Descripción: SOMBRILLAS Aplicaciones: JIMNY 3DR	Numero del parte: 0078338BC Tiempo de instalacion: 0.15h
GR	Περιγραφή: Ηλιοπροστασία Χρήση: JIMNY 3DR	Αρ. ο εξαρτ.: 0078338BC Χρονος συναρμολογησης: 0.15h

Contents	Ref.	Description	QTY
	1	Sun protection	3
	2	Holder A	6
	3	Holder B	4
	4		
	5		

Inhalt	Bez.	Beschreibung	STK.
	1	Sonnenschutz	3
	2	Halter A	6
	3	Halter B	4
	4		
	5		

Contenu	Réf.	Désignation	QTÉ
	1	Protection contre le soleil	3
	2	Titulaire A	6
	3	Titulaire B	4
	4		
	5		

Imballo	Rif.	Descrizione	QTA
	1	Protezione solare	3
	2	Titolare A	6
	3	Titolare B	4
	4		
	5		

Contenido	Ref.	Descripción	UNID
	1	Protección solar	3
	2	Titular A	6
	3	Titular B	4
	4		
	5		

Περιεχόμενα	Αρ.	Περιγραφή	τεμ.
	1	Защита от солнца	3
	2	Держатель А	6
	3	Держатель В	4
	4		





